

How To Record a DVD from a mini DV Tape

On the Sony DVD Direct:

- Push the button on top of the Sony DVD Direct.
- Insert a Blank DVD + or -.
- First it will say **Format** while it is formatting the disc.
- Then it will say **Ready**.

On the Camcorder:

- Insert the mini DV tape.
- Rewind to the beginning, **◀**.
- Attach the data cable from the (source) camcorder (yellow ring).
- The other end of the cable (red, white, yellow) to the (destination) Sony DVD Direct.
- Press **Play ▶** on the camcorder.

On the Sony DVD Direct:

- Press **Record** on the Sony DVD Direct.
- Press **Pause** on the Sony DVD Direct, when you think the recording is over.
- If it is really over, then press **Stop** on the Sony DVD Direct
- Press the **Function** button on the Sony DVD Direct.
- If you are done copying onto the DVD select **Finalize** by pressing the **Select** button.
- It will ask you to Reconfirm press the **Function** button.
- Then to select Yes, press the **Select** Button.
- Wait until it is done.
- Now try to play it.
- If it is a DVD + it might only play in a DVD player.
- If it is a DVD - it might play in a computer.